

AUTOMATE | E

ARC TUBULAR AC MOTOR



7 YEAR WARRANTY



433 MHZ
BI-DIRECTIONAL



ELECTRONIC
LIMIT



QUIET
OPERATION



FAVORITE
POSITION



LEVEL CONTROL

AUTOMATE | E tubular AC motors combine the simple, intuitive features of ARC “Automate Radio Communication” with the higher lifting capacity of an AC motor for larger shade applications.

Leveling Control allows for precise positioning of individual or multiple shades ensuring perfect alignment every time whilst bi-directional communication ensures you can always keep track of your shades position when integrated into smart home applications.

FEATURES:

- Electronic Limits
- A/C Line Voltage (available for both 100V-120V & 220V-240V applications)
- 433 MHz Bi-Directional RF Communication
- Leveling Control
- Favorite Position
- Roller & Tilt Modes
- “Slim Head” design Reduces Light Gaps
- Quiet Operation



CONTENTS

| | | |
|-----------|--|-----------|
| 1 | ASSEMBLY | 5 |
| 2 | WIRING | 6 |
| 2.1 | Power options | 6 |
| 3 | P1 BUTTON FUNCTIONS | 7 |
| 3.1 | Motor state test | 7 |
| 3.2 | Motor configuration options | 7 |
| 4 | INITIAL SET-UP | 8 |
| 4.1 | Pair motor with controller | 8 |
| 4.2 | Check motor direction | 8 |
| 4.3 | Set limits | 9 |
| 5 | ADJUSTING LIMITS | 10 |
| 5.1 | Adjust upper limit | 10 |
| 5.2 | Adjust lower limit | 10 |
| 6 | ADDING OR REMOVING CONTROLLERS AND CHANNELS | 11 |
| 6.1 | Using motor P1 button | 11 |
| 6.2 | Using a pre-existing controller | 11 |
| 7 | FAVORITE POSITIONING | 12 |
| 7.1 | Set a favorite position | 12 |
| 7.2 | Send shade to favorite position | 12 |
| 7.3 | Delete favorite position | 12 |
| 8 | TILT & ROLLER MODE | 13 |
| 8.1 | Enter tilt mode | 13 |
| 8.2 | Enter roller mode (Default) | 13 |
| 9 | SLEEP MODE | 13 |
| 10 | TROUBLESHOOTING | 14 |

SAFETY INSTRUCTIONS

WARNING: Important safety instructions to be read before installation.

Incorrect installation can lead to serious injury and will void manufacturer's liability and warranty.



CAUTION

- Do not expose to moisture or extreme temperatures.
- Do not allow children to play with this device.
- Use or modification outside the scope of this instruction manual will void warranty.
- Installation and programming to be performed by a suitably qualified installer.
- For use within tubular blinds.
- Ensure correct crown and drive adaptors are used for the intended system.
- Keep antenna straight and clear from metal objects
- Do not cut the antenna.
- Use only Rollease Acmeda hardware.
- Before installation, remove any unnecessary cords and disable any equipment not needed for powered operation.
- Ensure torque and operating time is compatible with end application.
- Do not expose the motor to water or install in humid or damp environments.
- Motor is to be installed in horizontal application only.
- Do not drill into motor body.
- The routing of cable through walls shall be protected by isolating bushes or grommets.
- Ensure power cable and aerial is clear and protected from moving parts.
- If cable or power connector is damaged do not use.

Important safety instructions to be read prior to operation.


- It is important for the safety of persons to follow the enclosed instructions. Save these instructions for future reference.
- Persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge should not be allowed to use this product.
- Keep remote controls away from children.
- Frequently inspect for improper operation. Do not use if repair or adjustment is necessary.
- Keep motor away from acid and alkali.
- Do not force the motor drive.
- Keep clear when in operation.




1 ASSEMBLY

Please refer to Rollease Acmeda System Assembly Manual for full assembly instructions relevant to the hardware system being used.

Step 1. Cut roller tube to required length.




Step 2. Ensure roller tube is clean and free from burrs.




Step 3. Fit required crown, drive and bracket adapters.

Tube must be close fitting with chosen crown and drive adapters. Refer to Rollease Acmeda System Assembly Manual for recommended crown, drive, and bracket adapter kits.




Step 4. Slide Motor into tube.

Insert by aligning keyway in crown and drive wheel to the tube.



Step 5. Mount motorized tube onto brackets.

Refer to Rollease Acmeda System Assembly Manual for recommended crown, drive, and bracket adapter kits.




2 WIRING

2.1 Power options

Cut off the mains power supply

Connect the motor according to the information in the table below.



| Range | Neutral | Live | Earth |
|----------|---------|-------|----------------|
| 220-240V | Blue | Brown | Yellow / Green |
| 100-120V | White | Black | Green |



Ensure cable is kept clear of fabric.

Ensure antenna is kept straight and away from metal objects.

3 P1 BUTTON FUNCTIONS

3.1 Motor state test

This table describes the function of a short **P1** button press/release (<2 seconds) depending on current motor configuration.

| P1 Press | Condition | Function Achieved | Visual Feedback | Audible Feedback | Function Described |
|-------------|--|---|-------------------------------------|------------------|--|
| Short Press | If limit is NOT set | None | No Action | None | No Action |
| | If limits are set | Operational control of motor, run to limit. Stop if running | Motor runs | None | Operational control of motor after pairing and limit setting is completed first time |
| | If motor is in "Sleep Mode" & limits are set | Wake and control | Motor wakes and runs in a direction | None | Motor is restored from Sleep Mode and RF control is active |


3.2 Motor configuration options

The **P1** Button is utilized to administer motor configuration as described below and beginning in Section

Activate Pairing Mode




Hold **P1**



Sleep Mode




Reverse Direction



NOTE

Reverse motor direction from **P1** button only when motor does not have any limits.

Reset To Factory Settings




4 INTIAL SET-UP

4.1 Pair motor with controller

Select channel on controller.



Hold **P1** button on motor head.



Hold **STOP** on controller.



IMPORTANT

Consult user manual for your controller for information on selecting channel.

Motor Response




Motor Response



Motor is now in step mode and ready for setting limits

4.2 Check motor direction

To check travel direction of shade, press **UP** or **DOWN** on controller.



To reverse shade direction, hold both **UP** and **DOWN**.

Until the motor responds.



Quick Press = Step

Long Press = Continuous Travel

Motor Response



IMPORTANT

Damage to shade may occur when operating motor prior to setting limits. Attention should be given.



IMPORTANT

Reversing motor direction using this method is only possible during initial set-up.

4.3 Set limits

To save upper limit, hold **UP** and **STOP**.

Move shade to the desired highest or lowest position by pressing the **UP** or **DOWN** buttons on controller.



To save lower limit, hold **DOWN** and **STOP**.



IMPORTANT

Cycle shade up and down prior to setting limits to settle fabric

Motor Response



IMPORTANT

After setting limits, motor will automatically exit from initial set-up mode.

 **Initial set-up is now complete**

5 ADJUSTING LIMITS

5.1 Adjust upper limit

Hold **UP** and **STOP** on controller.



Move shade to the desired highest position by pressing the **UP** button.



To save upper limit, hold **UP** and **STOP**.



Motor Response



Motor Response



5.2 Adjust lower limit

Hold **DOWN** and **STOP** on controller.



Move shade to the desired lowest position by pressing the **DOWN** button.



To save lower limit, hold **DOWN** and **STOP**.



Motor Response




Motor Response



6 ADDING OR REMOVING CONTROLLERS AND CHANNELS

6.1 Using motor P1 button

Hold **P1** button on motor head.



Hold **STOP** on controller to add or remove.



Motor Response



Motor Response



6.2 Using a pre-existing controller

A= Existing controller or channel (to keep)

B= Controller or channel to add or remove


Press **P2** on existing controller.



Press **P2** on existing controller.



Press **P2** on new controller.



Motor Response



Motor Response



Motor Response



IMPORTANT

Consult user manual for your controller or sensor.

7 FAVORITE POSITIONING

7.1 Set a favorite position

Move shade to the desired position by pressing the **UP** or **DOWN** button on the controller.



Press **P2** on controller.



Motor Response



Press **STOP** on controller.



Motor Response



Press **STOP** on controller.



Motor Response



7.2 Send shade to favorite position

Hold **STOP** on controller.



7.3 Delete favorite position

Press **P2** on controller.



Motor Response



Press **STOP** on controller.



Motor Response



Press **STOP** on controller.



Motor Response



8 TILT & ROLLER MODE

8.1 Enter tilt mode

For slat adjustment on venetians.

Hold **UP** and **DOWN** on controller.

Press **STOP**.



Motor Response



Motor Response



8.2 Enter roller mode (Default)

Hold **UP** and **DOWN** on controller.

Press **STOP**.



Motor Response



Motor Response




9 SLEEP MODE

Enter Sleep Mode

Sleep mode is utilized to prevent a motor from moving during shipping of a fabricated shade

Hold **P1** button on the motor head




Motor Response



Exit Sleep Mode

Exit sleep mode once the shade is installed

Press and release **P1** button on the motor head



Motor Response



10 TROUBLESHOOTING

| Problem | Cause | Remedy |
|---|---|--|
| Motor is not responding | Batteries in wand are depleted | Replace 8 x AA alkaline batteries. |
| | A/C power supply not plugged in. | Check motor to power cable connection and AC plug. |
| | Transmitter battery is discharged | Replace battery |
| | Radio interference/shielding | Ensure transmitter is positioned away from metal objects and the aerial on motor or receiver is kept straight and away from metal |
| | Receiver distance is too far from transmitter | Move transmitter to a closer position |
| | Power failure | Check power supply to motor is connected and active |
| | Incorrect wiring | Check that wiring is connected correctly (refer to motor installation instructions) |
| Cannot program a single Motor (multiple motors respond) | Multiple motors are paired to the same channel. | Always reserve an individual channel for programming functions |
| | | SYSTEM BEST PRACTICE - Provide an extra 15 channel controller in your multi motor projects, that provides individual control for each motor for programming purposes |
| | | Place all other motors into sleep mode (ref to P1 button function overview - Section 3) |

ROLLEASE ACMEDA
AUSTRALIA

110 Northcorp Boulevard,
Broadmeadows VIC 3047
T +61 3 9355 0100 | F +61 3 9355 0110

Queensland Branch
Unit 2/62 Borthwick Avenue,
Murarrie QLD 4172

ROLLEASE ACMEDA
USA

200 Harvard Avenue
Stamford, CT 06902 6320
T +1 203 964 1573 | F +1 203 964 0513

ROLLEASE ACMEDA
EUROPE

Via Conca Del Naviglio 18, Milan
(Lombardia) Italy
T +39 02 8982 7317 | F +39 02 8982 7317

info@rolleaseacmeda.com
rolleaseacmeda.com
